

JALECO



BIG STRIKER™

INSTRUCTION MANUAL



JALECO EUROPE

Rowlandson House, 289 Ballards Lane
Finchley, London N12 8NP United Kingdom
Tel.081-446-8431 Fax.081-445-6493

JALECO USA, INC.

310 Era Drive, Northbrook, IL 60062 U.S.A.
Tel.708-480-1811 Fax.708-480-9231

JALECO LTD.

2-19-7 Yohga, Setagaya-ku, Tokyo 158, Japan
Tel.03-3708-4830 Fax.03-3708-4822 Telex.J27891




BIG STRIKER™

EDGE CONNECTOR DIAGRAM (EDGE CONNECTOR OF JAMMA SPECS.)


COMPONENT SIDE			SOLDER SIDE	
GND	1	A	GND	
GND	2	B	GND	
HEADPHONE L&R(-)				
+5V	3	C	+5V	
+5V	4	D	+5V	
	5	E		
+12V	6	F	+12V	
KEY TO PREVENT ERRONEOUS INSERTION	7	H	KEY TO PREVENT ERRONEOUS INSERTION	
COIN METER #1	8	J	COIN METER #2	
	9	K		
SPEAKER 1 (+)	10	L	SPEAKER 1 (-)	
HEADPHONE L (+)				
	11	M		
VIDEO RED	12	N	VIDEO GREEN	
VIDEO BLUE	13	P	VIDEO SYNC	
VIDEO GND	14	R	SERVICE SWITCH	
	15	S		
COIN SW #1	16	T	COIN SW #1	
START SW #1	17	U	START SW #2	
1P UP	18	V	2P UP	
1P DOWN	19	W	2P DOWN	
1P LEFT	20	X	2P LEFT	
1P RIGHT	21	Y	2P RIGHT	
1P PUSH 1	22	Z	2P PUSH 1	
1P PUSH 2	23	a	2P PUSH 2	
	24	b		
	25	c		
	26	d		
GND	27	e	GND	
GND	28	f	GND	

SPEAKER #2 (+)	1	2	SPEAKER #2 (-)
HEADPHONE R (+)			



- THE EDGE CONNECTOR USED IS JAMMA 3.96 PITCH
- THE CONNECTOR USED FOR SPEAKER 2 IS 2.5 PITCH

● CONTROLS



- 8 DIRECTIONS
- SIDE SCROLLING
- 3 BUTTONS

●DIP SWITCH 1

(No.)				COIN CHUTE 1				COIN CHUTE 2			
				1	2	3	4	5	6	7	8
1	COIN	1	CREDIT	OFF	OFF	OFF	OFF				
1	"	2	"	ON	OFF	OFF	OFF				
1	"	3	"	OFF	ON	OFF	OFF				
1	"	4	"	ON	ON	OFF	OFF				
1	"	5	"	OFF	OFF	ON	OFF				
1	"	6	"	ON	OFF	ON	OFF				
2	"	1	"	OFF	ON	ON	OFF				
3	"	1	"	ON	ON	ON	OFF				
4	"	1	"	OFF	OFF	OFF	ON				
2	"	3	"	ON	OFF	OFF	ON				
1	COIN	1	CREDIT					OFF	OFF	OFF	OFF
1	"	2	"					ON	OFF	OFF	OFF
1	"	3	"					OFF	ON	OFF	OFF
1	"	4	"					ON	ON	OFF	OFF
1	"	5	"					OFF	OFF	ON	OFF
1	"	6	"					ON	OFF	ON	OFF
2	"	1	"					OFF	ON	ON	OFF
3	"	1	"					ON	ON	ON	OFF
4	"	1	"					OFF	OFF	OFF	ON
2	"	3	"					ON	OFF	OFF	ON
FREE PLAY				ON	ON	ON	ON	ON	ON	ON	ON

●DIP SWITCH 2

(No.)		1	2	3	4	5	6	7	8							
SCREEN	REGULAR	OFF														
	INVERSE	ON														
DIFFI- CULTY LEVEL	STANDARD									OFF	OFF					
	HARD									ON	OFF					
	EASY									OFF	ON					
	VERY HARD									ON	ON					
GAME TIME	STANDARD											OFF	OFF			
	SHORT											ON	OFF			
	LONG											OFF	ON			
	REALLY SHORT											ON	ON			
DEMO SOUND	ON						OFF									
	OFF						ON									
CREDITS NEEDED TO PLAY	2 CREDITS							OFF								
	1 CREDITS							ON								
TEST MODE	ON								OFF							
	OFF								ON							

- SOME MONITOR SCREENS ARE INVERTED. IF THIS IS THE CASE, PLEASE SET THE SWITCH IN THE OPPOSITE DIRECTION. THE SCREEN DIRECTION SHOULD CHANGE. (THE PLAYER'S CONTROLS SHOULD REMAIN THE SAME.)
- ALL SWITCHES ARE SET TO OFF WHEN IT LEAVES THE FACTORY FOR SHIPMENT.
- MAKE SURE TO TURN OFF THE POWER BEFORE SETTING THE DIP SWITCHES.
- IF DIP SWITCH 2. #8. IS SET TO ON, WHEN THE POWER IS TURNED ON, THE TEST MODE WILL RUN. USE THE 1P JOYSTICK TO MAKE YOUR SELECTION AND THE 1P START BUTTON TO EXECUTE.

JALECO

